

product

INSTALLATION GUIDE

T60 SERIES SCULLERY SINKS

- 1) Your Griffin C60 series Scullery Sink is shipped with the legs unattached. Turn your sink upside down on a protected surface and insert the legs completely inside the gussets.
- 2) There is a set screw opening on the gusset into which you insert the 5/16 in. set screw and tighten with an allen wrench. Your set screws are located in a bag taped to the back side of the backsplash.
- 3) Turn your sink right-side up. For uneven floor surfaces there is an adjustment available in each bullet foot.

GRiFFiN